

# Product Structures



## Carbon Change

It is a time to check the carbon brush when your die grinder is not working at full power or you get burning smell or it shows big blue sparks.

Open the side cap of die grinder with the help of small spanner to change the carbon brush.



# Installation Instructions

## A. Attachment / Accessory Installation

**1** Press the Collet Change Button and turn the collet



**2** Remove the collet cap and insert the desired collet



**3** Insert the attachment and tighten the collet cap with small wrench



## B. Flexible Shaft Installation

**1** Remove Black Collar and insert 3mm size collet



**2** Pass collet cap through inner spring of flexible shaft and insert inner spring in the collet



**3** Tighten the lower end of flexible shaft on die grinder below collet cap



**4** Insert allen key in hole below collet cap to hold spring to change accessories



## C. Universal Chuck (Accessory & Shaft Installation)

Hold the chuck button and turn the chuck in clockwise and anti clockwise direction to open and close the mouth to insert attachment



Remove the black collar and insert the inner wire of flexible shaft in universal chuck and tighten it. Tighten the flexible shaft at place of collar

